

Quick Start Guide - Connecting Ubiquiti Unifi Cameras

G3 PRO

1. Enter the camera IP Address in web browser (you may need a network scan to find IP address)

Default user info:
Username: UBNT
Password: UBNT

2. To reveal RTSP Stream - While in CONFIGURE tab, change mode to "standalone". Camera will restart and the RTSP URL will be shown in CONFIGURE tab, under Video Quality section

CONFIGURE NETWORK SYSTEM

Mode

Standalone

VIDEO QUALITY

RTSP Stream

High (1920x1080)

RTSP URL: rtsp://

Width: 1920

Height: 1080

Bitrate

NOTE: for security, make sure you change your password*

3. Go into your MONITOREAL account. Choose +Add Camera Manually and enter the RTSP URL along with the same login information from your UBNT camera. Your camera should get added within seconds.

Home / Cameras

Camera search + Add camera manually

*NOTE: You can change user log in information in SYSTEM tab